

# HS

Horizontal split case pump

Installation and operating instructions



Installation and operating instructions

<http://net.grundfos.com/qr/i/99296580>

be  
think  
innovate

**GRUNDFOS** 

# English (GB) Installation and operating instructions

## Original installation and operating instructions

These installation and operating instructions describe HS.

Sections 1-5 give the information necessary to be able to unpack, install and start up the product in a safe way.

Sections 6-12 give important information about the product, as well as information on service, fault finding and disposal of the product.

## CONTENTS

	Page
<b>1. General information</b>	<b>2</b>
1.1 Symbols used in this document	2
<b>2. Receiving the product</b>	<b>3</b>
2.1 Inspecting the product	3
<b>3. Installing the product</b>	<b>3</b>
3.1 Mechanical installation	3
3.2 Electrical connection	6
3.3 Pipes	7
3.4 Inlet pipe guidelines	9
<b>4. Starting up the product</b>	<b>11</b>
4.1 Prestart checks	11
4.2 Priming	11
4.3 Startup	12
4.4 Final alignment	13
4.5 Greasing the grid coupling	14
<b>5. Storing and handling the product</b>	<b>15</b>
5.1 Handling the product	15
5.2 Temporary storage	15
<b>6. Product introduction</b>	<b>16</b>
6.1 Applications	16
6.2 Pumped liquids	16
6.3 Identification	16
<b>7. Operating the product</b>	<b>19</b>
7.1 Operating checks	19
7.2 Frequency of starts and stops	19
7.3 Operating at reduced flow and/or head	19
<b>8. Servicing the product</b>	<b>19</b>
8.1 Maintaining the product	19
<b>9. Taking the product out of operation</b>	<b>21</b>
9.1 Short-time shutdown	21
9.2 Long-term shutdown	21
<b>10. Fault finding the product</b>	<b>22</b>
<b>11. Technical data</b>	<b>25</b>
11.1 Operating conditions	25
11.2 Flange forces and torques	27
<b>12. Disposing of the product</b>	<b>27</b>



Prior to installation, read this document and the online version of the installation and operating instructions. Installation and operation must comply with local regulations and accepted codes of good practice.

## 1. General information

Grundfos HS horizontal split case pumps are supplied either as a complete pump with motor, base frame and approved coupling guard or as a bare shaft pump.

These instructions apply to both types.

The HS pump can be driven by an electric motor or another type of driver. In the following we assume that the pump is driven by an electric motor.

### 1.1 Symbols used in this document

#### 1.1.1 Warnings against hazards involving risk of death or personal injury

##### DANGER



Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.

##### WARNING



Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.

##### CAUTION



Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The text accompanying the three hazard symbols DANGER, WARNING and CAUTION is structured in the following way:

##### SIGNAL WORD



##### Description of hazard

Consequence of ignoring the warning.  
- Action to avoid the hazard.

### 1.1.2 Other important notes



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



Tips and advice that make the work easier.

## 2. Receiving the product

### 2.1 Inspecting the product

The pump is delivered from factory in a crate or wooden box specially designed for transport by a forklift truck or a similar vehicle.

Upon receipt, check the pump visually to determine whether any damage has happened to it during transport or handling.

Check especially for these points:

1. broken or cracked equipment, including base frame, motor or pump feet and flanges
2. broken motor fan cover, bent eyebolts or damaged terminal box
3. missing parts.

Parts or accessories are sometimes wrapped individually or fastened to the equipment.

If any damage or losses have occurred, promptly notify Grundfos' representative and the carrier's agent at once.



Bolts for HS bare shaft pumps have US threads for which inch tools are required.

Bolts for coupling guard and for mounting of pump and motor on the base frame have metric threads.

## 3. Installing the product

### 3.1 Mechanical installation

#### WARNING


##### Crushing hazard



Death or serious personal injury  
- Make sure that all installations are performed by persons experienced in the placement, alignment and connection of pumping equipment.

#### 3.1.1 Location

Install the pump with accessibility for inspection and maintenance. Allow ample space and headroom for the use of an overhead crane or hoist sufficiently strong to lift the unit.



**Fig. 1** HS pump with accessibility for inspection and headroom for the use of an overhead crane

Install the pump as close as possible to the supply of pumped liquid, so that the inlet pipe is as short and direct as possible.

#### 3.1.2 Foundation

We recommend that you install the pump on a concrete foundation which is heavy enough to provide permanent and rigid support for the entire pump. The foundation must be capable of absorbing any vibration, normal strain or shock. We recommend that the weight of the concrete foundation is 3 times the weight of the complete pump unit. For specific requirements, consult the contractor, engineer, or established industry standards.

In installations where silent operation is particularly important, we recommend a foundation that is up to 5 times as heavy as the complete pump unit.

TM04\_0382\_1016

### 3.1.3 Vibration dampers

Vibration dampers may be required to prevent pump vibrations from being transmitted to the building or the pipes. In order to select the right type of vibration damper, you need this information:

- Forces transmitted through the damper.
- Motor speed. Take the motor speed into account in the case of speed control.
- Desired dampening in %. The recommended value is 70 %.

The choice of vibration dampers differs from installation to installation. In certain cases a wrong damper may increase the vibration level. Vibration dampers must therefore be sized by the supplier of the vibration dampers.

### 3.1.4 Expansion joints

Expansion joints provide these advantages:

- absorption of thermal expansion and contraction of pipes caused by variations in liquid temperature
- reduction of mechanical influences in connection with pressure surges in the pipes
- isolation of structure-borne noise in the pipes (only rubber bellows expansion joints).



Do not fit expansion joints to make up for inaccuracies in the pipes, such as centre displacement or misalignment of flanges.

Fit the expansion joints at a minimum distance of 2 pipe diameters (DN) away from the pump flange on the inlet side. This prevents turbulence in the joints, thus ensuring optimum inlet conditions and minimum pressure drop on the outlet side.

At flow velocities greater than 2.4 m/s, we recommend that you fit larger expansion joints matching the pipes.

### 3.1.5 Foundation and preliminary alignment procedure

The foundation and preliminary alignment procedure has four steps:

1. pouring of foundation
2. shimming of base frame
3. preliminary alignment
4. grouting.

### Pouring of foundation

We recommend the following procedure to ensure a good foundation:

1. Pour the foundation without interruptions to within 19-32 mm of the final level. Use vibrators to ensure that the concrete is evenly distributed. The top surface must be well scored and grooved before the concrete sets. This provides a bonding surface for the grout.
2. Embed anchor bolts in the concrete as shown in fig. 2. Allow enough bolt length to reach through grout, shims, lower base frame, nuts and washers.




Fig. 2 Typical anchor bolt design

Let the foundation cure for several days before the base frame is shimmed and grouted.

### Shimming of base frame




Fig. 3 Shimming of base frame and levelling of pump

TM04 0383 0608

TM04 0381 0608

1. Lift/jack up the base frame to the final level 19-32 mm above the concrete foundation, and support the base frame by means of blocks and shims, both at the anchor bolts and midway between bolts. See fig. 3.
2. Level the base frame by adding or removing shims under the base frame. See fig. 3.
3. Tighten the anchor bolt nuts against the base frame. Make sure the pipes can be aligned to the pump flanges without putting strain on the pipes or flanges.

### Preliminary alignment

#### DANGER

#### Electric shock



Death or serious personal injury

- Before starting work on the pump, make sure that the power supply has been switched off and that it cannot be accidentally switched on.

The pump and motor are pre-aligned on the base frame from the factory. Some deformation of the base frame may occur during transport and it is therefore essential to check alignment at the installation site prior to final grouting.

Inaccurate alignment results in vibration and excessive wear on the bearings, shaft and wear rings.



Carry out alignment of the motor only, as pipe strain will occur if the pump is shifted.

Carry out alignment of the motor by placing shims of different thickness under the motor. If possible, replace several thin shims with one thick shim.

The preliminary alignment procedure has four steps:

#### 1. Checking coupling clearance

Make sure that the gap between the coupling halves is equal to the values in the table and that the keyways are 180 ° displaced.

For a coupling with an outside diameter of $\varnothing$ [mm]	Coupling clearance [mm]	
	Nominal	Tolerance
$\varnothing 90-213$	3.2	0/-1
$\varnothing 251-270$	4.8	0/-1
$\varnothing 306-757$	6.4	0/-1

#### 2. Checking soft foot on pump and motor

A pump or a motor having a soft foot can be compared to sitting down at a table and finding that the table rocks when someone leans on it.

Technically, it is a condition where the feet of a motor or a pump are not at the same level as the base plate.

To check for soft foot, set the pump or motor on its base plate and bolt it down. Set up a dial gauge on one foot, loosen the hold-down bolt, and watch the dial gauge. If the dial gauge indicator moves while loosening the bolt, the pump or motor has soft foot. The movement measured by the dial gauge indicates how many shims you need to level the pump or motor. Repeat this procedure at all four corners.

If the pump was installed a long time ago, the stresses induced in the pump casing by soft foot can cause permanent deformation of the casing.

#### 3. Checking parallel alignment

Place a straight edge across both coupling rims at the top, the bottom and both sides. See fig. 4. After each adjustment, recheck all features of alignment. Parallel alignment is correct when the measurements show that all points of the coupling faces are within  $\pm 0.2$  mm of each other.




Fig. 4 Checking parallel alignment

#### 4. Checking angular alignment

Insert a pair of inside callipers or a taper gauge at four points at 90 ° intervals around the coupling. See fig. 5. The angular alignment is correct when the measurements show that all points of the coupling faces are within  $\pm 0.2$  mm of each other.




Fig. 5 Checking angular alignment


Recheck the coupling clearance and tighten the set screws on the couplings.

## Grouting

Grouting compensates for uneven foundation, distributes the weight of the unit, dampens vibrations and prevents shifting. Use an approved, non-shrinking grout. If you have questions or doubts about the grouting, consult an expert on grouting.

Proceed as follows:

1. Build a strong formwork around the foundation to contain the grout.
2. Soak the top of the concrete foundation thoroughly, then remove surface water.
3. Fill the formwork with grout up to the top edge of the base frame. See fig. 6. Allow the grout to dry thoroughly before attaching the pipe to the pump. 24 hours is sufficient time with approved grouting procedure.
4. When the grout has thoroughly hardened, check the anchor bolt nuts and tighten them if necessary.
5. Approximately two weeks after the grout has been poured, or when the grout has thoroughly dried, apply an oil-based paint to the exposed edges of the grout to prevent air and moisture from getting in contact with the grout.



**Fig. 6** Sectional view of foundation with anchor bolt, grouting and base frame

TM04 0384 0608

## 3.2 Electrical connection

The electrical connections must be carried out by an authorised electrician in accordance with local regulations.

### DANGER

#### Electric shock

Death or serious personal injury

- Before you remove the terminal box cover and before you remove or dismantle the pump, make sure that the power supply has been switched off and that it cannot be accidentally switched on.



The operating voltage and frequency are marked on the motor nameplate.

Make sure that the motor is suitable for the power supply of the installation site.

Carry out the electrical connections as shown on the motor nameplate or in the wiring diagram on the back of the terminal box cover.

For further information, contact the motor supplier.

### DANGER

#### Electric shock

Death or serious personal injury

- Whenever you use powered equipment in explosive surroundings, observe the rules and regulations generally or specifically imposed by the relevant responsible authorities or trade organisations.



### 3.2.1 Frequency converter operation

You can connect all three-phase motors to a frequency converter.

However, frequency converter operation often exposes the motor insulation system to a heavier load and causes the motor to be more noisy than usual due to eddy currents caused by voltage peaks.



If in doubt whether the supplied motor can handle frequency converter operation, contact the motor supplier.

In addition, large motors driven via a frequency converter will be loaded by bearing currents.

When the pump is operated via a frequency converter, check the following operating conditions:

Operating conditions	Action
2-, 4- and 6-pole motors of 45 kW and up	Check that one of the motor bearings is electrically isolated. Contact Grundfos.
Noise-critical applications	Fit a dU/dt filter between the motor and the frequency converter. It reduces the voltage peaks and thus the noise.
Particularly noise-critical applications	Fit a sinusoidal filter.
Cable length	Fit a cable that meets the specifications laid down by the frequency converter supplier. The length of the cable between the motor and frequency converter affects the motor load.
Supply voltage up to 500 V	Make sure that the motor is suitable for frequency converter operation.
Supply voltage between 500 V and 690 V	<ul style="list-style-type: none"> <li>Fit a dU/dt filter. It reduces the voltage peaks and thus the noise.</li> <li>Or make sure that the motor has reinforced insulation.</li> </ul>
Supply voltage of 690 V and upwards	<ul style="list-style-type: none"> <li>Fit a dU/dt filter.</li> <li>Make sure that the motor has reinforced insulation.</li> </ul>

### 3.3 Pipes



Protective covers are fitted to the inlet and outlet ports to prevent foreign bodies from entering the pump during transportation and installation. Remove these covers from the pump before connecting any pipes.

#### Inlet and outlet pipe

In order to minimise friction losses and hydraulic noise in the pipes, choose a pipe that is one or two sizes larger than the pump inlet and outlet ports. Typically, flow velocities must not exceed 2 m/s (6 ft/sec) for the inlet pipe (port) and 3 m/s (9 ft/sec) for the outlet pipe (port).

Make sure that the NPSH available (NPSHA) is higher than the NPSH required (NPSHR). NPSH = Net Positive Suction Head.

#### 3.3.1 General precautions

When installing the pipes, observe these precautions:

1. Always run the pipes directly to the pump.
2. Do not move the pump to the pipes. This could make the final alignment impossible and cause stress to the pump flanges and pipes.



Make sure that both the inlet and outlet pipes are independently supported near the pump so that no strain is transmitted to the pump when you tighten the flange bolts. Use pipe hangers or other supports with necessary spacing to provide support.

3. When you use expansion joints in the pipe system, fit the joints at a minimum distance of 2 pipe diameters away from the pump on the inlet side. This prevents turbulence in the joints, thus ensuring optimum inlet conditions.
4. Install the pipes as straight as possible and avoid unnecessary bends. Where necessary, use 45 ° or long-sweep 90 ° fittings to reduce friction loss.
5. Make sure that all pipe joints are tight.
6. Where you use flanged joints, ensure that the inside diameters match properly.
7. Remove burrs and sharp edges when making up joints.
8. Make sure that the pipes do not cause stress or strain in the pump.
9. Provide for expansion of pipe material by means of expansion joints on both sides of the pump.
10. Always allow sufficient space and accessibility for maintenance and inspection.

### 3.3.2 Inlet pipes

Place the pump below system level whenever possible. This will facilitate priming, assure a steady liquid flow and provide a positive suction head.



The sizing and installation of the inlet pipe is extremely important.

You can avoid many NPSH problems if you install the inlet pipe properly. See section [3.3.1 General precautions](#).

In section [12. Disposing of the product](#), common inlet pipe installations are illustrated for two situations:

- flooded systems  
Closed systems and open systems where the liquid level is above the pump inlet.
- suction lift systems  
Closed systems and open systems where the liquid level is below the pump inlet.

### 3.3.3 Valves in the inlet pipe

If the pump is operating under permanent suction lift conditions, install a non-return valve in the inlet pipe to avoid having to prime the pump each time it is started. The non-return valve must be of the flap type or a foot-valve with a minimum of pressure loss.

### 3.3.4 Outlet pipe

The outlet pipe is usually preceded by a non-return valve and an isolating or throttle valve. The non-return valve protects the pump against excessive counterpressure and reverse rotation of the pump and prevents backflow through the pump in case of operational stop or failure of the motor.

In order to minimise friction losses and hydraulic noise in the pipes, flow velocities must not exceed 3 m/s (9 ft/sec) in the outlet pipe (port).

On long horizontal runs, keep the pipe as level as possible.

Avoid high spots, such as loops as they will collect air and throttle the system or lead to uneven pumping.

### 3.3.5 Auxiliary pipes

#### Drains

Install the drain pipes from the pump casing and stuffing boxes to a convenient disposal point.

#### Flushing pipes

- Pumps fitted with stuffing boxes

When the inlet pressure is below the ambient pressure, supply the stuffing boxes with liquid to provide lubrication and prevent the ingress of air. This is normally achieved via a flushing pipe from the outlet side to the stuffing box. You can fit a control valve or orifice plate in the flushing pipe to control the pressure to the stuffing box.

If the pumped liquid is dirty and cannot be used for flushing the packing rings, we recommend a separate clean, compatible liquid supply to the stuffing box at 1 bar (15 psi) above the inlet pressure.

- Pumps fitted with mechanical seals  
Seals requiring re-circulation will normally be provided with a flushing pipe from the pump casing.

### 3.3.6 Measuring instruments

To ensure continuous monitoring of operation, we recommend that you install pressure gauges on the pump inlet and outlet flanges. The pressure gauge on the inlet side must be capable of measuring vacuum. The pressure tappings must only be opened for test purposes. The measuring range of the outlet side pressure gauge must be minimum 20 % above the maximum pump outlet pressure.

When measuring with pressure gauges on the pump flanges, note that a pressure gauge does not register dynamic pressure (velocity pressure). The diameters of the inlet and outlet flanges are different, and this results in different flow velocities in the two flanges. Consequently, the pressure gauge on the outlet flange will not show the pressure stated in the technical documentation, but a value which may be lower.




### 3.4 Inlet pipe guidelines

#### 3.4.1 Common guidelines

##### Avoid airlocks or turbulence in the inlet pipe

Never use reducers in a horizontal inlet pipe as shown in fig. 8. Instead, use an eccentric reducer as illustrated in fig. 7.

**Correct**




Eccentric reducer


**Fig. 7** Correctly mounted reducer

TM04 0093 4907

**Wrong**



Concentric reducer



Turbulent flow


**Fig. 8** Reducers resulting in airlocks and turbulence

TM04 0092 4907

#### 3.4.2 Flooded systems

Closed systems and open systems where the liquid level is above the pump inlet.

**Correct**



Eccentric reducer

Pipe sloping down towards pump

**Fig. 9** Correctly mounted inlet pipe


TM04 0148 4907

#### 3.4.3 Suction lift systems

Closed systems and open systems where the liquid level is below the pump inlet.

Install the inlet pipe sloping upwards towards the inlet port. Any high point in the pipe will be filled with air and thus prevent proper operation of the pump. When reducing the pipe to the inlet port diameter, use an eccentric reducer with the eccentric side down to avoid airlocks.

**Correct**




Eccentric reducer

Pipe sloping up towards pump

**Fig. 10** Correctly mounted inlet pipe

TM04 0098 4907

**Wrong**



Airlock

Pipe sloping down towards pump

Eccentric reducer


**Fig. 11** Inlet pipe resulting in airlocks

TM04 0097 4907

### 3.4.4 Inlet pipe if the feed line comes in different horizontal planes

Avoid high spots, such as loops, as they will collect air and throttle the system or lead to uneven pumping.


**Correct**



TM04 0095 4907

**Fig. 12** Correctly mounted inlet pipe

**Wrong**



TM04 0094 4907


**Fig. 13** Inlet pipe resulting in airlocks

### 3.4.5 Inlet pipe with a horizontal elbow in the feed line

Make sure that the liquid flow is evenly distributed to both sides of the double-suction impeller.

There is always an uneven, turbulent flow through an elbow. See below. If you install an elbow in the inlet pipe near the pump in a position other than vertical, more liquid will enter one side of the impeller than the other. This will result in heavy, unbalanced thrust loads overheating the bearings, causing rapid wear and reducing the hydraulic performance.


**Correct**



TM04 0150 4907

**Fig. 14** Recommended inlet pipe installation with a length of straight pipe between horizontal elbow and pump


**Wrong**



TM04 0149 4907

**Fig. 15** Unbalanced loading of a double-suction impeller due to uneven flow through a horizontal elbow close to the pump

### 3.4.6 Installations with vertical inlet pipe in confined space



TM04 0096 4907

**Fig. 16** Inlet diffuser (1) in the inlet pipe

## 4. Starting up the product

The startup procedure for the pumps has four steps:

1. Prestart checks. See section [4.1 Prestart checks](#).
2. Priming. See section [4.2 Priming](#).
3. Starting. See section [4.3 Startup](#).
4. Final alignment. See section [4.4 Final alignment](#).



Only start the pump when you have gone through all the prestart checks.

### 4.1 Prestart checks

Prestart checks have four steps:

1. Bearings
2. Stuffing boxes
3. Pressure gauge
4. Direction of rotation.

#### 4.1.1 Bearings

Make sure that all bearings are properly lubricated. See section [8.1.3 Lubrication](#).

#### 4.1.2 Stuffing boxes

Make sure that the stuffing box packing rings have been properly tightened.



This does not apply to pumps with mechanical shaft seals.

#### 4.1.3 Pressure gauges

Make sure that the pressure gauge connections are closed.

#### 4.1.4 Direction of rotation

Check the direction of rotation in the following way:

1. Disconnect the two coupling halves between pump and motor.
2. Make sure that the motor shaft can turn freely.
3. Start the motor briefly to check the direction of rotation. The correct direction of rotation is indicated by the arrows on the pump casing.



The direction of rotation of the pump is not always the same as the flow direction.

4. If the direction of rotation is wrong, correct it by interchanging two phases on the motor.

### DANGER

#### Electric shock

Death or serious personal injury  
- Before interchanging two phases, make sure that the power supply has been switched off and that it cannot be accidentally switched on.



5. Check the direction of rotation again.
6. Reassemble the coupling and the guards.

## 4.2 Priming



If not primed properly, the pump will not deliver liquid.

### Closed systems or open systems where the liquid level is above the pump inlet (flooded systems)

Fill the inlet pipe and pump with liquid and vent them before the pump is started. Proceed as follows:

1. Close the outlet isolating or throttle valve.
2. Loosen the vent screw (17) and the plug for shaft seal flushing (20d).




Fig. 17 Position of the vent valve and plug for shaft seal flushing

### WARNING

#### Hot or cold surface

Death or serious personal injury



- Pay attention to the direction of the vent hole, and ensure that the escaping water does not cause injury to persons or damage to the motor or other components.



- In hot-water installations, pay special attention to the risk of injury caused by scalding hot water and hot surfaces.  
- In cold-liquid installations, pay special attention to the risk of injury caused by cold liquids and cold surfaces.

3. Slowly open the isolating valve in the inlet pipe until a steady flow of liquid runs out of the vent hole.
4. Rotate the shaft by hand, if possible, while priming and venting to free entrapped air from the impeller channels.
5. Tighten the vent screw and completely open the isolating or throttle valve(s).

TM04 2592 2708

### Open systems where the liquid level is below the pump inlet (suction lift systems)

Fill the inlet pipe and pump with liquid and vent them before the pump is started. Proceed as follows:

#### Suction lift system with foot valve

1. Close the outlet isolating or throttle valve and open the isolating valve in the inlet pipe.
2. Remove the vent screw and connect a priming device to a drain hole.
3. Fill the inlet pipe and casing with liquid at a pressure of 1 to 2 bar from an external source until the inlet pipe and pump are completely filled with liquid.
4. Rotate the shaft by hand while priming and venting to free entrapped air from the impeller channels.
5. Refit the vent screw and tighten it securely.
6. You can fill the inlet pipe with liquid and vent it before you connect the pipe to the pump. You can also install a priming device before the pump.

#### Suction lift system without foot valve

1. Connect an external vacuum pump to the vent hole on the top of the pump casing.
2. Close the outlet isolating or throttle valve and open the isolating valve in the inlet pipe.
3. Open the valves between the pump and vacuum pump.
4. Start the external vacuum pump.
5. Pump until the inlet pipe and the pump are completely filled with liquid.
6. Rotate the shaft by hand while priming and venting to free entrapped air from the impeller channels.
7. When the liquid runs out of the vacuum pump, stop the external vacuum pump and close the valves between the pump and vacuum pump.



Never let the pump run dry. The pump is not self-priming.

Dry-running will cause serious damage to the stuffing boxes, shaft seals, wear rings and shaft sleeves.

#### 4.2.1 Opening of valves

1. Open the valves for the flushing liquid to the stuffing boxes.
2. Completely open the isolating valve on the inlet side of the pump and leave the outlet isolating or throttle valve partly open.

### 4.3 Startup



Make sure that the pump is filled with liquid. The pump must not run dry. Dry-running will cause serious damage to the stuffing boxes, shaft seals, wear rings and shaft sleeves.

1. Start the pump.
2. Vent the pump during startup by loosening the vent screw until a steady flow of liquid runs out of the vent hole.

#### WARNING

##### Hot or cold surface

Death or serious personal injury



- Pay attention to the direction of the vent hole, and ensure that the escaping water does not cause injury to persons or damage to the motor or other components.



- In hot-water installations, pay special attention to the risk of injury caused by scalding hot water and hot surfaces.  
- In cold-liquid installations, pay special attention to the risk of injury caused by cold liquids and cold surfaces.

3. When the pipe system has been filled with liquid, slowly open the outlet isolating or throttle valve until it is completely open.
4. Adjust the stuffing box gland (stuffing boxes only). With the pump running, tighten the stuffing box gland to allow a leakage of 40-60 drops per minute. This is required for shaft sleeve lubrication. Tighten the stuffing box gland evenly to provide uniform compression on the packing rings. After initial startup, additional packing rings and adjustment may be required until the packing rings are properly seated.



Do not allow a stuffing box to run dry, and do not overtighten the stuffing box gland to eliminate leaking as the shaft sleeve will become damaged.

## 4.4 Final alignment




Make the final alignment by shimming the motor only.

1. Let the pump run until it has reached its operating temperature under normal operating conditions (approximately 1 hour).
2. Stop the pump.
3. Remove the coupling guard.
4. Check the alignment on the coupling by means of dial gauges. See below.

### Checking coupling alignment by means of dial gauges


Alternatively, use laser equipment for the final alignment.



**Fig. 18** The end view of the coupling is seen from the motor


The coupling alignment procedure has four steps:

### Parallel alignment - vertically




1. Mount the dial gauge (2) in position 0° (12 o'clock). See fig. 18.
2. Make the index lines on the two coupling halves. See fig. 18.
3. Set the dial gauge pointer to zero, turn the motor and pump shaft simultaneously until the dial gauge is in position 180° (6 o'clock) and check that the index lines are still in line.
4. Read the dial gauge (2). If the dial gauge shows a deflection exceeding  $\pm 0.2$  mm, add or remove the shims under the motor until the reading of the dial gauge is within the allowable tolerance of  $\pm 0.2$  mm.

### Parallel alignment - horizontally



1. Turn the motor and pump shaft to 270° (9 o'clock).
2. Set the dial gauge pointer to zero, turn the motor and pump shaft to 90° (3 o'clock) and check that the index lines are still in line.
3. Read the dial gauge. If the dial gauge shows a deflection exceeding  $\pm 0.2$  mm, move the motor sideways until the reading of the dial gauge is within the allowable tolerance of  $\pm 0.2$  mm.
4. Remove the dial gauge (2).

### Angular alignment - horizontally



1. Mount the dial gauge (1) in position 90° (3 o'clock). See fig. 18.
2. Make the index lines on the two coupling halves. See fig. 18.
3. Set the dial gauge pointer to zero, turn the motor and pump shaft simultaneously until the dial gauge is in position 270° (9 o'clock) and check that the index lines are still in line.
4. Read the dial gauge (1). If the dial gauge shows a deflection exceeding  $\pm 0.2$  mm, move the motor sideways until the deflection is halved.
5. Set the dial gauge pointer to zero, turn the motor and pump shaft simultaneously until the dial gauge is in position 90° (3 o'clock) and read the dial gauge (1) again.
6. Now the reading must be within the allowable tolerance of  $\pm 0.2$  mm. If not, repeat the procedure.


TM03 2941 4905

TM03 2942 4905

TM03 0210 4504

TM03 2939 4905

## Angular alignment - vertically



TM03 2940 4905

1. Turn the motor and pump shaft until the dial gauge (1) is in position 0 ° (12 o'clock).
2. Set the dial gauge pointer to zero, turn the motor and pump shaft simultaneously until the dial gauge is in position 180 ° (6 o'clock) and check that the index lines are still in line.
3. Read the dial gauge (1). If the dial gauge shows a deflection exceeding  $\pm 0.2$  mm, add or remove the shims under the motor until the deflection is halved.
4. Set the dial gauge pointer to zero, turn the motor and pump shaft simultaneously until the dial gauge is in position 0 ° (12 o'clock) and read the dial gauge (1) again.
5. Now the reading must be within the allowable tolerance of  $\pm 0.2$  mm. If not, repeat the procedure.
6. Remove the dial gauge (1).



The coupling tolerances may differ from coupling make to coupling make. For the standard coupling, the allowable tolerance is  $\pm 0.2$  mm. For other coupling types, see the coupling data supplied with the pump.

Finish the alignment procedure by refitting and tightening the coupling.

## 4.5 Greasing the grid coupling

Pack the spaces between and around the grid with as much lubricant as possible and wipe off the excess lubricant so that it is flush with the top of the grid. See section [8.1.3 Lubrication](#).

Position the seals on the hubs so they line up with the grooves in the coupling cover. Position the gaskets on the flanges of the lower coupling cover half and assemble the covers so that the matching marks are on the same side.

Push the gaskets in until they stop against the seals and secure the coupling cover halves with the fasteners provided and tighten them properly. Make sure that the gaskets stay in position during this tightening procedure.

Once the coupling is completely assembled, remove both of the lubricating plugs in the covers, insert a lubricating nipple in one of the lubricating holes, pump in lubricant until it is forced out of the opposite lubricating hole and refit the two lubrication plugs.

The installation is now complete.

### WARNING

#### Crushing hazard



- To protect persons from rotating machine parts, always install all guards after the installation is complete and before starting the pump.

## 5. Storing and handling the product

### 5.1 Handling the product

#### WARNING


##### Crushing hazard

Death or serious personal injury

- Handling must be performed by qualified persons.
- When unloading the pump, lift equally at four or more points on the base frame. Do not lift by the motor or by the pump. Do not lift by the flanges or by the eyebolts on the motor.




Lift the pump by means of nylon straps and shackles.



TM06 8170 4816

**Fig. 19** How to lift and handle the HS pumps



TM04 0380 0608

**Fig. 20** How to lift and handle the HS bare shaft pumps

### 5.2 Temporary storage

If you do not store or operate the pump soon after arrival, store it in a clean, dry place with slow, moderate changes in ambient temperature. Protect the pump from moisture, dust, dirt and foreign bodies. Prior to and during storage we recommend these precautions:

1. Make sure that the bearings are filled with the recommended grease to prevent moisture from entering around the shaft. See section [8.1.3 Lubrication](#).
2. Make sure that the inlet and outlet ports and all other openings are covered with cardboard, wood or masking tape to prevent foreign objects from entering the pump.
3. Cover the unit with a tarpaulin or other suitable covering if it is to be stored where there is no protective covering.
4. Rotate the shaft two turns every two weeks to prevent corrosion of the bearing surfaces and the stuffing box or shaft seal faces due to moisture.

## 6. Product introduction

### 6.1 Applications

Grundfos HS horizontal split case pumps are typically used in these applications:

- circulation in heating and air conditioning systems, water condensing and boiler feed systems
- liquid transfer and pressure boosting in various industrial systems
- water distribution and water treatment in public water systems.

### 6.2 Pumped liquids

Clean, thin, non-aggressive liquids, not containing solid particles or fibres. Do not pump liquids that will attack the pump materials chemically.

#### CAUTION



#### Hot liquid

Minor or moderate personal injury

- Do not exceed the maximum operating temperature stated on the nameplate.

When pumping liquids with a density and/or viscosity higher than that of water, the head and flow will be reduced. Alternatively, use motors with correspondingly higher outputs.

The stuffing box packing rings or mechanical shaft seal O-rings chosen must be suitable for the liquid to be pumped.

Special stuffing box packing rings or shaft seal O-rings may be required if you use the pump for pumping treated water:

- at temperatures above 80 °C (176 °F).
- containing additives to prevent system corrosion, calcareous deposits, etc. (this may be the case in heating and ventilating systems).

When pumping liquids other than water, select an appropriate stuffing box or shaft seal. For further information, contact Grundfos.

### 6.3 Identification

The type designation and rating information of Grundfos horizontal split case pumps are stated on the nameplate. See fig. 21. The type designation includes model number, size and type.

Permanent records for this pump are kept under its year-week code and serial number (pos. 4 and pos. 5) and this number must therefore be stated in all correspondence and spare parts orders.

For more information about weight, see the label on the packaging.

#### 6.3.1 Nameplate




Fig. 21 Nameplate of CE-marked HS pump

Pos.	Description
1	Type designation
2	Product number
3	Place of production
4	Production year and week
5	Serial number
6	Maximum pressure and temperature
7	Rated flow rate (duty-point flow)
8	Head at rated flow rate (duty-point head)
9	Speed
10	Country of production
11	Reference to lubrication instruction. See section <a href="#">8.1.3 Lubrication</a> .



### 6.3.2 Type key

The type key is an explanation of the product type designation. See fig. 21, pos. 1.

Example	HS	125	-100	-305X	/273.1	, (W)	1	F1	D	S	BAQE	1
<b>Type range</b>												
HS horizontal version												
<b>Nominal diameter of the inlet port (DN)</b>												
<b>Nominal diameter of the outlet port (DN)</b>												
<b>Maximum impeller diameter [mm]</b>												
If suffix is used, "X" = different impeller design												
<b>Actual impeller diameter [mm]</b>												
<b>Potable-water code (optional)</b>												
ACS or WRAS certified pump												
<b>Pump variant</b>												
1: Basic version, grease-lubrication, pump with motor, common base frame, standard coupling												
2: Grease-lubrication, bare shaft pump with common base frame, standard coupling												
3: Grease-lubrication, bare shaft pump												
4: Grease-lubrication, pump with motor, separate base frames, spacer coupling												
5: Grease-lubrication, bare shaft pump with separate base frame, spacer coupling												
6: Oil-lubrication, pump with motor, common base frame, standard coupling												
7: Oil-lubrication, bare shaft pump with common base frame, standard coupling												
8: Oil-lubrication, bare shaft pump												
9: Oil-lubrication, pump with motor, separate base frames, spacer coupling												
A: Oil-lubrication, bare shaft pump with separate base frame, spacer coupling												
X: Special variant												
<b>Code for pipe connection</b>												
F1: 10 bar, DIN PN 10												
G1: 10 bar, ANSI 125LB/150LB												
F2: 16 bar, DIN PN 16												
G2: 16 bar, ANSI 250LB/300LB												
F3: 25 bar, DIN PN 25												
G3: 25 bar, ANSI 250LB/300LB												
XX: Special flanges												
<b>Code for shaft and sleeve materials (sleeve is only used for 25 bar pump)</b>												
D: SS420 and no sleeve												
A: SS420 and SS304												
E: SS304 and no sleeve												
C: SS420 and SS316												
J: SS316 and no sleeve												
B: SS420 and bronze												
L: Duplex stainless steel and no sleeve												
K: Duplex stainless steel and duplex stainless steel												
X: Special												

**Example** HS 125 -100 -305X /273.1 , (W) 1 F1 D S BAQE 1

**Code for pump casing and impeller materials**

S: Cast iron and SS304	Q: Ductile iron and SS304
C: Cast iron and SS316	G: Ductile iron and SS316
B: Cast iron and bronze	A: Ductile iron and bronze
D: Cast iron and duplex stainless steel	H: Ductile iron and duplex stainless steel
U: SS304 and SS304	J: SS316 and SS316
K: Duplex stainless steel and duplex stainless steel	
X: Special	

**Code for shaft seal or stuffing box**

BAQE: Rubber bellows seal, unbalanced, carbon*/SiC, EPDM
BAQV: Rubber bellows seal, unbalanced, carbon*/SiC, FKM
AAQE: O-ring seal, unbalanced, carbon*/SiC, EPDM
AAQV: O-ring seal, unbalanced, carbon*/SiC, FKM
DAQE: O-ring seal, balanced, carbon*/SiC, EPDM
DAQV: O-ring seal, balanced, carbon*/SiC, FKM
SAQE: Rubber bellows seal, balanced, carbon*/SiC, EPDM
SAQV: Rubber bellows seal, balanced, carbon*/SiC, FKM
BBQE: Rubber bellows seal, unbalanced, carbon/SiC, EPDM
BBQV: Rubber bellows seal, unbalanced, carbon/SiC, FKM
ABQE: O-ring seal, unbalanced, carbon/SiC, EPDM
ABQV: O-ring seal, unbalanced, carbon/SiC, FKM
DBQE: O-ring seal, balanced, carbon/SiC, EPDM
DBQV: O-ring seal, balanced, carbon/SiC, FKM
SBQE: Rubber bellows seal, balanced, carbon/SiC, EPDM
SBQV: Rubber bellows seal, balanced, carbon/SiC, FKM
BQQE: Rubber bellows seal, unbalanced, SiC/SiC, EPDM
BQQV: Rubber bellows seal, unbalanced, SiC/SiC, FKM
AQQE: O-ring seal, unbalanced, SiC/SiC, EPDM
AQQV: O-ring seal, unbalanced, SiC/SiC, FKM
DQQE: O-ring seal, balanced, SiC/SiC, EPDM
DQQV: O-ring seal, balanced, SiC/SiC, FKM
SQQE: Rubber bellows seal, balanced, SiC/SiC, EPDM
SQQV: Rubber bellows seal, balanced, SiC/SiC, FKM
BBVP: Rubber bellows seal, carbon/aluminium oxide, nitrile rubber
SNEK: Stuffing box with synthetic polymer packing rings, uncooled, with internal barrier fluid

**Direction of rotation**

(Pump direction of rotation as seen from the motor end)

- 1: Clockwise
- 2: Counterclockwise

\* Antimony, not approved for potable water.

The example shown is an HS 125-100-305/273.1, standard type with standard coupling, DIN PN 10 flange, cast iron pump casing with SS304 impeller, BAQE mechanical shaft seal and clockwise direction of rotation.

## 7. Operating the product

### 7.1 Operating checks

1. Check the pump and pipes for leaks.
2. Check and record the pressure gauge readings for future reference.
3. Check the differential pressure. If the differential pressure is lower than anticipated, the motor may be overloaded. See description of measuring instruments in section [3.3.6 Measuring instruments](#).
4. Measure the motor current consumption and compare the result with the rated current stated on the motor nameplate. In case of overload, throttle the outlet isolating or throttle valve until the motor is no longer overloaded.
5. Check the bearings for lubrication and temperature. Normal temperature is 70 °C (158 °F). The maximum temperature depends on the type of lubrication. See the lubricating plate on the pump.

Stop the pump immediately if you notice any defects. Do not start the pump unless the defects have been remedied. See section [10. Fault finding the product](#). Report immediately to the supplier that you cannot remedy the defects.



The operating checks apply both during the startup procedure and when checking the pump during normal operation.

### 7.2 Frequency of starts and stops

The recommended maximum number of starts per hour below apply to complete pumps with a motor supplied by Grundfos. The values are recommendations only.

#### 0 to 50 kW

15 starts per hour. The motor must be stopped for at least 3 minutes before restart.

#### 51 to 100 kW

10 starts per hour. The motor must be stopped for at least 5 minutes before restart.

#### 101 to 315 kW

5 starts per hour. The motor must be stopped for at least 10 minutes before restart.

#### Greater than 315 kW

2 starts per hour.

### 7.3 Operating at reduced flow and/or head

Do not operate the pump at a flow rate below 10 % of the maximum flow rate stated on the nameplate or with the outlet isolating or throttle valve closed.

Operating the pump under such conditions may involve the risk of the pump being overheated. To prevent possible damage, use protective devices such as liquid temperature relay, bearing temperature relay, inlet pressure monitoring, etc.

If a pump is operated at reduced head, the flow will increase and the motor will consume more current than normal. This will result in overheating of the motor. In such situations, throttle the valve on the outlet side, instead. If an automatic throttle valve is installed, this can be done automatically.

## 8. Servicing the product

### DANGER

#### Toxic material



Death or serious personal injury

- If a pump has been used for a liquid injurious to health or toxic, the pump will be classified as contaminated.

If you want Grundfos to service the pump, contact Grundfos with details about the pumped liquid, etc. before you return the pump for service. Otherwise Grundfos can refuse to accept the pump for service.

### 8.1 Maintaining the product

### DANGER

#### Electric shock



Death or serious personal injury

- Before starting work on the pump, make sure that the power supply has been switched off and that it cannot be accidentally switched on.

#### 8.1.1 General information

Routine maintenance is essential to maintain the pump in a good condition.

A high degree of cleanliness must be maintained during all maintenance procedures.

### 8.1.2 Frequency of inspections

Carry out inspections in accordance with the maintenance table below.

Depending on operating and environmental conditions together with a comparison of previous inspections, the frequency of inspections may be altered to maintain satisfactory operation of the pump.

Every week	<ul style="list-style-type: none"> <li>• Visually check for leaks.</li> <li>• Check for vibrations.</li> <li>• Hand test the bearing housing for any sign of temperature rise.</li> <li>• Check correct leaking from the stuffing boxes (approximately 40-60 drops per minute).</li> </ul>
Every month	<ul style="list-style-type: none"> <li>• Check the pump bearing temperature.</li> </ul>
Every 6 months	<ul style="list-style-type: none"> <li>• Check the shaft for scores.</li> <li>• Check the alignment of the pump and motor.</li> <li>• Check the fixing bolts and tighten, if necessary.</li> <li>• Check the coupling for wear.</li> </ul>
Every year	<ul style="list-style-type: none"> <li>• Check whether the grease in the pump bearings has hardened.</li> <li>• Check the rotating assembly for wear.</li> <li>• Check the wear ring clearances.</li> </ul>

#### CAUTION

##### Sharp element

Minor or moderate personal injury

- Wear protective gloves to protect yourself against sharp edges on the impeller and wear rings.



Between the regular maintenance inspections, be aware of signs of motor or pump trouble.

Common symptoms are listed in section [10. Fault finding the product](#).

Remedy any fault immediately and avoid costly repairs and shutdowns.

### 8.1.3 Lubrication

#### Pump bearings

Pump bearings are lubricated prior to delivery.

We recommend relubricating intervals of 2000 operating hours. Depending on duty conditions this may, however, vary.

To refill the bearings with fresh grease, follow this procedure:

1. Remove the bearing cap.
2. Add enough grease to fill up 1/3 of the ball bearing.
3. Note the quantity required.
4. Refit the bearing cap.

Repeat this procedure the first three times. Based on the first three relubrications, determine the correct quantity of grease required.

For future relubrications, apply the established quantity of grease through the lubricating nipples. You do not have to remove the bearing caps.

For every 10,000 operating hours or every two years:

1. Remove the bearing caps from pump.
2. Remove old grease.
3. Thoroughly clean the bearing caps.
4. Refill the bearings with fresh grease.
5. Refill the bearing caps completely with fresh grease.
6. Refit the bearing caps in accordance with the assembly instructions.
7. Start the pump briefly several times to distribute the grease in the bearings and to prevent overheating of the grease.

Grease specifications: See [Ball bearing grease](#) below.



Do not overgrease.

Too much grease can cause overheating and premature bearing failure.

#### Motor bearings

Lubricate the motor bearings in accordance with the indications on the motor nameplate.

Grease specifications: See [Ball bearing grease](#) below.

#### Ball bearing grease

Manufacturer	Lubricant
Shell	Dolium R
Exxon	Polyrex
Chevron	SRI grease NLGI 2 Black pearl NLGI 2
Philips	Polytac
Texaco	Polystar RB

## Grid coupling

A grid coupling must be regreased at intervals. Normally, the interval is one year, but it can be shorter if the environment is aggressive or the operating conditions are harsh. Use the same grease for the coupling as for the ball bearings. See [Ball bearing grease](#).

Proceed like this:

1. Remove the coupling guards.
2. Remove the two lubricating plugs.
3. Pump grease into one of the lubricating holes to push the old grease out of the opposite hole.
4. Keep pumping until the fresh grease comes out.
5. Refit and fasten the two plugs.
6. Mount the coupling guards again.

## 9. Taking the product out of operation

The following shutdown procedures apply to most normal shutdowns. If the pump is to be inoperative for a long time, follow the storage procedures in section [9.2 Long-term shutdown](#).

1. Always close the outlet or throttle valve before stopping the pump. Close the valve slowly to prevent hydraulic shock, but make sure that the pump does not run against a closed valve for more than a few seconds.
2. Switch off the power supply to the motor.

### 9.1 Short-time shutdown

1. For overnight or temporary shutdown periods under non-freezing conditions, the pump may remain filled with liquid. Make sure the pump is fully primed before restarting.
2. For short or frequent shutdown periods at temperatures below 0 °C, keep the liquid moving within the pump casing and insulate or heat the pump exterior to prevent freezing.

### 9.2 Long-term shutdown


For long shutdown periods or to isolate the pump for maintenance, close the inlet and outlet valves. If no inlet valve is fitted and the pump has positive inlet height, drain all liquid from the inlet pipe to terminate the liquid flow into the pump inlet port. If applicable, turn off any external source of cooling or lubricating liquid to the stuffing boxes or shaft seals. Remove the plugs in the pump drain and vent tappings, as required, and drain all liquid from the pump casing. Remove the stuffing box glands and packing rings, if applicable.

## CAUTION

### Hot or cold surface

Minor or moderate personal injury

- Make sure that the escaping water does not cause injury to persons or damage to the motor or other components.
- In hot-water installations, pay special attention to the risk of injury caused by scalding hot water.
- In cold-liquid installations, pay special attention to the risk of injury caused by cold liquid and cold surfaces.



Drain plug, pump casing    Drain plug, inlet port and outlet port

**Fig. 22** Example of drain plugs

1. If freezing conditions will prevail during long shutdown periods after draining the pump, blow out all liquid in passages and airlocks using compressed air. You can prevent freezing of pumped liquid by filling the pump with antifreeze solution.

## WARNING

### Harm to health

Death or serious personal injury

- Do not use antifreeze solution if you use the pump for public or potable-water supply.



2. Rotate the shaft by hand monthly to coat the bearings with lubricant and delay oxidation and corrosion.
3. Where applicable, follow the motor manufacturer's storage recommendations.



Do not tighten the vent screw or refit the drain plug until the pump is to be used again.

TM04-0378-0608

## 10. Fault finding the product

### DANGER

#### Electric shock

Death or serious personal injury

- Before you remove the terminal box cover and before you remove or dismantle the pump, make sure that the power supply has been switched off and that it cannot be accidentally switched on.



Faults										Causes
A	B	C	D	E	F	G	H	I	J	K: Reference numbers to remedies.
										K
A:										The pump is not primed, lack of priming liquid, incomplete priming. 1
B:										Loss of priming liquid. 2
C:										The suction lift or static lift is too high. 3
D:										The outlet pressure is too high (measured at the outlet port). 4
E:										The speed is too low. 5
F:										Wrong direction of rotation. 6
G:										The impeller is completely clogged. 7
H:										The inlet pipe is partially blocked. 8
I:										Air leak in the inlet pipe or flange. 9
J:										Air leak in the stuffing box. The flushing pipe may be blocked. 10
										Cavitation; insufficient NPSH (depending on installation). 11
										The impeller or wear rings are worn. 12
										Defective packing rings. 13
										The non-return valve is too small or partially obstructed. The cross section of the non-return valve port must be at least as large as the cross section of the inlet pipe. 14
										The inlet pipe is not immersed deeply enough. 15
										The impeller diameter is too small. This is the most probable cause, if none of the above causes apply. 16

Faults										Causes
A: The pump delivers no liquid.										
B: The pump does not deliver enough liquid.										
C: The pump does not create enough pressure.										
D: The pump loses liquid after running for a short time.										
E: The pump consumes too much power.										
F: The motor is overloaded.										
G: Vibrations.										
H: Cavitation noise.										
I: The pump bearings are overheated.										
J: The pump operates for a short time and then stops.										K: Reference numbers to remedies.
A	B	C	D	E	F	G	H	I	J	K
		•								Obstruction in the casing. 17
		•	•	•			•			Air or gases in the liquid. 18
		•		•						The actual duty point of the pump lies to the right of the specified duty point on the pump curve. The result is lower head, higher flow and higher power consumption. 19
				•	•					The viscosity or specific gravity of the pumped liquid is higher than that of water. 20
				•	•	•		•		The shaft is bent due to damage. 21
				•	•	•		•		Mechanical failure of the bearing and/or impeller. 22
				•		•		•		Misalignment. 23
				•	•					Electrical defects. 24
				•	•		•			The speed is too high. 25
						•				The foundation is not rigid enough. 26
								•		The lubricating oil or grease is dirty or contaminated. 27

No.	Cause	Remedy
1	The pump is not primed, lack of priming liquid, incomplete priming.	Fill the pump and inlet pipe completely with pumped liquid.
2	Loss of priming liquid.	Mend possible leaks in the inlet pipe, joints and fittings. Vent the pump casing to remove accumulated air.
3	The suction lift or static lift is too high.	Reduce the difference in height between the water reservoir or water supply and the pump.
4	The outlet pressure is too high.	Make sure that valves in the outlet pipe are fully open.
5	The speed is too low.	1. Make sure that the motor receives full voltage. 2. Make sure that the frequency is correct. 3. Make sure that all phases are connected.
6	Wrong direction of rotation.	Compare the direction of rotation with the directional arrow on the pump casing. If required, change the direction of rotation by interchanging two phases in the motor.
7	The impeller is completely clogged.	Dismantle the pump and clean the impeller.
8	The inlet pipe is partially blocked.	Remove any obstructions in the inlet pipe.

No.	Cause	Remedy
9	Air leak in the inlet pipe or flange.	Replace or repair the defective pipe section or flange.
10	Air leak in the stuffing box.	Clean the flushing pipe. Replace the stuffing box packing rings, if necessary.
11	Cavitation; insufficient NPSH (depending on installation).	<ol style="list-style-type: none"> <li>1. Increase the net positive suction head by placing the pump in a lower position.</li> <li>2. Pressurise the inlet vessel.</li> </ol>
12	The impeller or wear rings are worn.	Replace the impeller and/or wear rings. If necessary, also replace the bearings and the shaft.
13	Defective packing rings.	Replace the packing rings.
14	The non-return valve is too small or partially obstructed.	Replace or clean the non-return valve.
15	The inlet pipe is not immersed deeply enough.	Extend the inlet pipe so that the risk of sucking air is eliminated.
16	The impeller diameter is too small.	Check with Grundfos if you can use a larger impeller. If not, reduce the outlet pipe friction losses. But be careful not to seriously overload the motor.
17	Obstruction in pump casing.	Dismantle the pump and remove the obstruction.
18	Air or gases in the liquid.	Remove the gas or air from the pumped liquid. See 11) above.
19	The actual duty point of the pump lies to the right of the specified duty point on the pump curve. The result is lower head, higher flow and higher power consumption.	Install an orifice plate immediately after the outlet flange. The orifice plate will raise the system characteristic or increase the counterpressure thus increasing the head and lowering the flow. The size of the orifice plate must be adapted so that the pressure corresponds to the required duty point.
20	The viscosity or specific gravity of the pumped liquid is higher than that of water.	Use a larger motor. Consult Grundfos for recommended size. Test the liquid for viscosity and specific gravity.
21	The shaft is bent due to damage.	Check the deflection of the shaft. The total indicator runout must not exceed 0.05 mm. Possibly replace the shaft.
22	Mechanical failure of bearing and/or impeller.	Check the bearings and the impeller for damage. Replace the bearings or the impeller, if necessary.
23	Misalignment.	Realign the pump and motor.
24	Electrical defects.	Check that the voltage and frequency of the power supply are correct. Remedy the possible defects in the motor. Check that the motor is properly cooled.
25	The speed is too high.	Check that the frequency of the power supply corresponds to the frequency stated on the motor nameplate.
26	The foundation is not rigid enough.	Retighten the anchor bolt nuts. Make sure that the foundation is made according to the installation and operating instructions.
27	The lubricating oil or grease is dirty or contaminated.	Clean the bearings and bearing housings according to the instructions and relubricate the bearings.



## 11. Technical data

### 11.1 Operating conditions

#### 11.1.1 Ambient temperature and altitude

The ambient temperature and the installation altitude are important factors for the motor life, as they affect the life of the bearings and the insulation system.

If the ambient temperature or the pump installation altitude exceeds the values below, the motor must not be fully loaded due to the risk of overheating. Overheating may result from excessive ambient temperature or the low density and consequently low cooling effect of the air. In such cases, it may be necessary to use a motor with a higher output.




Bearing service intervals are shorter at temperatures above 40 °C.

#### Legend

Pos.	Maximum ambient temperature at full load [°C]	Maximum altitude above sea level [m]
1	40	1000
2	60	3500
3	55	2750

Motor	Number of poles	IE2 and IE3 motors		Other motor sizes	
		P2 [kW]	Pos.	P2 [kW]	Pos.
MG	2	11-22	2	-	-
	4	1.5 - 15	2	-	-
	2	30-90 <sup>1)</sup>	3	-	-
Siemens	4	18.5 - 200 <sup>1)</sup>	3	250-630	1
	6	11-160 <sup>1)</sup>	3	200-315	1
MMG-G	2	11-90	1	-	-
	4	1.5 - 630	1	-	-
	6	11-132	1	-	-
MMG-H	2	11-90	2	-	-
	4	1.5 - 315	2	-	-
	6	11-132	2	-	-

<sup>1)</sup> At ambient temperatures above 40 °C, the motor temperature class is changed from B to F.



**Fig. 23** Motor output in relation to temperature/altitude

### Example

Figure 23 shows that you must reduce the load of an MG motor to 88 % when installed 4750 m above sea level.

At an ambient temperature of 75 °C, you must reduce the load of the motor to 78 % of the rated output.

If you install the pump 4750 m above sea level at an ambient temperature of 75 °C, do not load the motor more than  $88\% \times 78\% = 68.6\%$  of the rated output.


### 11.1.2 Liquid temperature

The maximum liquid temperature marked on the pump nameplate depends on the mechanical shaft seal used:

Temperature range for NBR: 0 up to 100 °C.

Temperature range for FKM: 15-100 °C.

### 11.1.3 Pressure in the pump



**Fig. 24** Pressure in the HS pump

### Maximum outlet pressure



The maximum outlet pressure is the pressure (p) stated on the pump nameplate.

### Minimum inlet pressure

The minimum inlet pressure must correspond to the NPSH curve for the pump + a safety margin of minimum 0.5 metres head.

NPSH appears from the data booklet and Grundfos Product Center.

### Maximum inlet pressure

The inlet pressure + pump pressure must be lower than the maximum pressure (p) of the pump. This is stated on the nameplate. See fig. 21, position 7.

### Minimum flow rate

The pump must not run against a closed outlet valve as this will cause an increase in the temperature or formation of steam in the pump. This may cause shaft damage, impeller erosion, short life of bearings, damage to stuffing boxes or mechanical shaft seals due to stress or vibration.

The continuous flow rate must be at least 25 % of the flow rate in the best efficiency point.

### Maximum flow rate

The maximum flow rate must not exceed the value stated on the nameplate. If the maximum flow rate is exceeded, cavitation and overload may occur.


### Sound pressure level

See page 29 and 30.

TM04 4914 2209

TM04 0062 4907

## 11.2 Flange forces and torques



TM06 6281 1016

Fig. 25 Flange forces and torques

### Horizontal pump, side branch, y-axis

Diameter DN	Force [N]				Torque [Nm]			
	F <sub>y</sub>	F <sub>z</sub>	F <sub>x</sub>	ΣF*	M <sub>y</sub>	M <sub>z</sub>	M <sub>x</sub>	ΣM*
25	340	280	300	520	180	210	270	390
32	420	340	360	660	225	255	330	480
40	500	400	440	780	270	315	390	570
50	660	540	600	1040	300	345	420	615
65	840	680	740	1320	330	360	450	660
80	1000	820	900	1580	345	390	480	705
100	1340	1080	1200	2100	375	435	525	780
125	1580	1280	1420	2480	450	570	630	915
150	2000	1620	1800	3140	525	615	750	1095
200	2680	2160	2400	4180	690	795	975	1440
250	3340	2700	2980	5220	945	1095	1335	1965
300	4000	3220	3580	6260	1290	1485	1815	2670
350	4660	3760	4180	7300	1650	1905	2325	3420
400	5320	4300	4780	8340	2070	2385	2910	4290
450	5980	4840	5380	9380	2550	2940	3585	5280
500	6640	5380	5980	10420	3075	3540	4335	6390
550	7300	5920	6580	11460	3660	4215	5130	7590
600	7960	6460	7180	12500	4320	4980	6060	8970

\* ΣF and ΣM are the vector sums of the forces and torques.

If not all loads reach the maximum permissible value, one of the values is allowed to exceed the normal limit. Contact Grundfos for further information.

## 12. Disposing of the product

Dispose of this product or parts of it in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

Subject to alterations.

## Appendix

## Airborne noise emitted by HS pumps

MG motors:

Motor [kW]	L <sub>pA</sub> [dB(A)]	
	50 Hz	
	2-pole	4-pole
1.5		47
2.2		48
3.0		52
4.0		48
5.5		51
7.5		52
11		60
15	60	54
18.5	60	
22	64	

Siemens motors:

Motor [kW]	L <sub>pA</sub> [dB(A)]			
	50 Hz			
	2-pole	4-pole	6-pole	
11			66	
15			56	
18.5			60	59
22			60	59
30	71	62	59	
37	71	66	60	
45	71	66	58	
55	71	67	58	
75	73	70	61	
90	73	70	61	
110	76	70	61	
132		70	61	
160		70	64	
200		70	68	
250		73	68	
315		73	71	
355		75		
400		75		
500		75		
560		78		
630		78		

Motor [kW]	$L_{pA}$ [dB(A)]					
	50 Hz			60 Hz		
	2-pole	4-pole	6-pole	2-pole	4-pole	6-pole
1.5		59			59	
2.2		63			63	
3.0		63			63	
3.7		63			63	
4.0		63			63	
5.5		64			65	
7.5		68			68	
11	70	68	62	78	68	59
15	72	75	65	81	75	62
18.5	72	75	69	81	75	66
22	72	75	70	81	75	67
30	73	78	74	86	78	71
37	73	78	75	86	78	72
45	73	80	75	87	80	72
55	78	83	81	88	82	79
75	80	83	81	90	83	79
90	80	85	84	91	85	81
110	84	85	84	91	85	81
132		88	84		85	81
160		88	86		85	82
200		90	86		90	82
220			86			82
250		90	87		90	82
315		90	87		90	85
335		90	87		90	85
355		90	87		90	90
375		90	90		90	90
400		90	90		90	95
450		90	90		90	95
500		90			90	
525		90			90	
560		90			90	
600		90			90	

MMG-H motors:

Motor [kW]	L <sub>pA</sub> [dB(A)]		
	50 Hz		
	2-pole	4-pole	6-pole
1.5		58	
2.2		60	
3		60	
4		61	
5.5		62	
7.5		62	
11	66	60	56
15	66	60	56
18.5	66	65	59
22	70	65	59
30	73	68	59
37	73	68	59
45	78	68	60
55	78	69	60
75	79	70	68
90	79	70	69
110		74	70
132		74	70
160		74	
200		76	
250		79	
315		80	

Subject to alterations.



**Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana km. 37.500 Centro  
Industrial Garin  
1619 Garin Pcia. de B.A.  
Phone: +54-3327 414 444  
Telefax: +54-3327 45 3190

**Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

**Austria**

GRUNDFOS Pumpen Vertrieb  
Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

**Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomsesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

**Belarus**

Представительство ГРУНДФОС в  
Минске  
220125, Минск  
ул. Шафарнянская, 11, оф. 56, БЦ  
«Порт»  
Тел.: +7 (375 17) 286 39 72/73  
Факс: +7 (375 17) 286 39 71  
E-mail: minsk@grundfos.com

**Bosnia and Herzegovina**

GRUNDFOS Sarajevo  
Zmaja od Bosne 7-7A,  
BH-71000 Sarajevo  
Phone: +387 33 592 480  
Telefax: +387 33 590 465  
www.ba.grundfos.com  
e-mail: grundfos@bih.net.ba

**Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo  
Branco, 630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

**Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

**Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

**China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
10F The Hub, No. 33 Suhong Road  
Minhang District  
Shanghai 201106  
PRC  
Phone: +86 21 612 252 22  
Telefax: +86 21 612 253 33

**COLOMBIA**

GRUNDFOS Colombia S.A.S.  
Km 1.5 vía Siberia-Cota Conj. Potrero  
Chico,  
Parque Empresarial Arcos de Cota Bod.  
1A.  
Cota, Cundinamarca  
Phone: +57(1)-2913444  
Telefax: +57(1)-8764586

**Croatia**

GRUNDFOS CROATIA d.o.o.  
Buzinski prilaz 38, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.hr.grundfos.com

**GRUNDFOS Sales Czechia and Slovakia s.r.o.**

Čajkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111

**Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

**Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

**Finland**

OY GRUNDFOS Pumput AB  
Trukkikuja 1  
FI-01360 Vantaa  
Phone: +358-(0) 207 889 500

**France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnes  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

**Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
e-mail: infoservice@grundfos.de  
Service in Deutschland:  
e-mail: kundendienst@grundfos.de

**Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

**Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor  
Siu Wai Industrial Centre  
29-33 Wing Hong Street &  
68 King Lam Street, Cheung Sha Wan  
Kowloon  
Phone: +852-27861706 / 27861741  
Telefax: +852-27858664

**Hungary**

GRUNDFOS Hungária Kft.  
Park u. 8  
H-2045 Törökbálint,  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

**India**

GRUNDFOS Pumps India Private  
Limited  
118 Old Mahabalipuram Road  
Thoraiakkam  
Chennai 600 096  
Phone: +91-44 2496 6800

**Indonesia**

PT. GRUNDFOS POMPA  
Graha Intirub Lt. 2 & 3  
Jln. Cililitan Besar No.454. Makasar,  
Jakarta Timur  
ID-Jakarta 13650  
Phone: +62 21-469-51900  
Telefax: +62 21-460 6910 / 460 6901

**Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

**Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290 / 95838461

**Japan**

GRUNDFOS Pumps K.K.  
1-2-3, Shin-Miyakoda, Kita-ku,  
Hamamatsu  
431-2103 Japan  
Phone: +81 53 428 4760  
Telefax: +81 53 428 5005

**Korea**

GRUNDFOS Pumps Korea Ltd.  
679 Floor, Aju Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

**Latvia**

SIA GRUNDFOS Pumps Latvija  
Deglava biznesa centrs  
Augusta Deglava iela 60, LV-1035, Rīga,  
Tālr.: + 371 714 9640, 7 149 641  
Faks: + 371 914 9646

**Lithuania**

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431



**Malaysia**

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguam U1/25  
Glenmarie Industrial Park  
40150 Shah Alam  
Selangor  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

**Mexico**

Bombas GRUNDFOS de México S.A. de  
C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

**Netherlands**

GRUNDFOS Netherlands  
Veluwezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

**New Zealand**

GRUNDFOS Pumps NZ Ltd.  
17 Beatrice Tinsley Crescent  
North Harbour Industrial Estate  
Albany, Auckland  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

**Norway**

GRUNDFOS Pumper A/S  
Strømsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

**Poland**

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo k. Poznania  
PL-62-081 Przeźmierowo  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

**Portugal**

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet de Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

**Romania**

GRUNDFOS Pompe România SRL  
Bd. Biruintei, nr 103  
Pantelimon county Ilfov  
Phone: +40 21 200 4100  
Telefax: +40 21 200 4101  
E-mail: romania@grundfos.ro

**Russia**

ООО Грундфос Россия  
ул. Школьная, 39-41  
Москва, RU-109544, Russia  
Тел. (+7) 495 564-88-00 (495)  
737-30-00  
Факс (+7) 495 564 8811  
E-mail grundfos.moscow@grundfos.com

**Serbia**

Grundfos Srbija d.o.o.  
Omladinskih brigada 90b  
11070 Novi Beograd  
Phone: +381 11 2258 740  
Telefax: +381 11 2281 769  
www.rs.grundfos.com

**Singapore**

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

**Slovakia**

GRUNDFOS s.r.o.  
Prievozská 4D  
821 09 BRATISLAVA  
Phona: +421 2 5020 1426  
sk.grundfos.com

**Slovenia**

GRUNDFOS LJUBLJANA, d.o.o.  
Leskovoška 9e, 1122 Ljubljana  
Phone: +386 (0) 1 568 06 10  
Telefax: +386 (0) 1 568 06 19  
E-mail: tehnika-si@grundfos.com

**South Africa**

GRUNDFOS (PTY) LTD  
Corner Mountjoy and George Allen  
Roads  
Wilbart Ext. 2  
Bedfordview 2008  
Phone: (+27) 11 579 4800  
Fax: (+27) 11 455 6066  
E-mail: lsmart@grundfos.com

**Spain**

Bombas GRUNDFOS España S.A.  
Camino de la Fuentequilla, s/n  
E-28110 Algete (Madrid)  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

**Sweden**

GRUNDFOS AB  
Box 333 (Lunnagårdsgatan 6)  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Telefax: +46 31 331 94 60

**Switzerland**

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-44-806 8111  
Telefax: +41-44-806 8115

**Taiwan**

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

**Thailand**

GRUNDFOS (Thailand) Ltd.  
92 Chaloeun Phrakiat Rama 9 Road,  
Dokmai, Pravej, Bangkok 10250  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

**Turkey**

GRUNDFOS POMPA San. ve Tic. Ltd.  
Sti.  
Gebze Organize Sanayi Bölgesi  
İhsan dede Caddesi,  
2. yol 200. Sokak No. 204  
41490 Gebze/ Kocaeli  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

**Ukraine**

Бізнес Центр Європа  
Столичне шосе, 103  
м. Київ, 03131, Україна  
Телефон: (+38 044) 237 04 00  
Факс.: (+38 044) 237 04 01  
E-mail: ukraine@grundfos.com

**United Arab Emirates**

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone  
Dubai  
Phone: +971 4 8815 166  
Telefax: +971 4 8815 136

**United Kingdom**

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 4TL  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

**U.S.A.**

GRUNDFOS Pumps Corporation  
17100 West 118th Terrace  
Olathe, Kansas 66061  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

**Uzbekistan**

Grundfos Tashkent, Uzbekistan The Rep-  
resentative Office of Grundfos Kazakhstan  
in Uzbekistan  
38a, Oybek street, Tashkent  
Телефон: (+998) 71 150 3290 / 71 150  
3291  
Факс: (+998) 71 150 3292

Addresses Revised 09.08.2017

be think innovate

---

**99296580** 0617

ECM: 1211021

The name Grundfos, the Grundfos logo, and **be think innovate** are registered trademarks owned by Grundfos Holding A/S or Grundfos A/S, Denmark. All rights reserved worldwide.  
© Copyright Grundfos Holding A/S

[www.grundfos.com](http://www.grundfos.com)

**GRUNDFOS** 